



TEMPTAG[®] THERMOMETER



Operating Instructions

INSTRUMENT OPERATION - Press the ON/OFF button to switch on. To switch off, press and hold the ON/OFF button for three seconds. There is no auto power-off feature.

MAX/MIN - Press MAX/MIN to swap between the two readings. To clear the reading whilst in MAX/MIN mode, hold down the button for three seconds to reset all readings. ' ---' will be displayed.

°C/°F - To switch from °C to °F, double press the ON/OFF button. When powered off this will power up in the last set scale/s. Factory setting is Centigrade.

BATTERY REPLACEMENT - The battery is located at the rear of the instrument. Remove the battery cover with a coin and turn in the direction of the arrow. Replace battery with a CR2032 lithium coin cell battery before re-tightening the battery cover.

BATTERY WARNING: KEEP OUT OF REACH OF CHILDREN.

If you think batteries might have been swallowed or placed inside any part of the body, seek immediate medical attention.



GUARANTEE - This instrument carries a one-year guarantee against defects in either components or workmanship. During this period, products that prove to be defective will, at the discretion of ETI, be either repaired or replaced without charge. The product guarantee does not cover damage caused by fair wear and tear, abnormal storage conditions, incorrect use, accidental misuse, abuse, neglect, misapplication or modification. Full details of liability are available within ETI's Terms & Conditions of Sale at etiltld.com. In line with our policy of continuous development, we reserve the right to amend our product specification without prior notice.



Supplied by
Electronic Temperature Instruments Ltd
Worthing · West Sussex · BN14 8HQ
01903 202151 · sales@etiltd.com · etiltld.com

